









↓



Lower Case
7 T8 Torx





Hard Drive
2 T8 Torx





HD Replacement
2 T8 Torx



↓





Optical Drive
2 T8 Torx



Modem
2 T6 Torx



Inverter
2 T6 Torx



DC-In Board
2 T6 Torx



↙ ↘



To organize your screws, simply place each screw in the appropriate box as you remove them from your laptop.



If you are not planning on immediately reassembling your laptop, you may want to tape the screws to this paper.

Due to model variations, the screws you remove may differ slightly from this guide.





Modem Filter Board
1 T8 Torx



↓



Modem Filter Board
1 T6 Torx





Logic Board
5 T8 Torx





Logic Board
1 T8 Torx



↓



Logic Board
1 T8 Torx



PC Card Cage
1 T8 Torx



PC Card Cage
1 T8 Torx

