

<p><b>Step 1</b></p> <p>⊕ 2 x 3.6 mm</p>	<p><b>Step 6</b></p> <p>⊕ 2 x 1.2 mm 1 x 1.6 mm</p>	<p><b>Step 10</b></p> <p>⊕ 1 x 1.8 mm 1 x 1.6 mm</p>	<p><b>Step 16</b></p> <p>⊕ 1 x 1.5 mm 1 x 2.3 mm</p>	<p><b>Step 19</b></p> <p>⊕ 2 x 1.3 mm</p>
<p><b>Step 20</b></p> <p>⊕ 1 x 1.2 mm</p>	<p><b>Step 24</b></p> <p>⊕ 2 x 2.3 mm ⊖ 3 x 2.7 mm</p>	<p><b>Step 29</b></p> <p>⊕ 1 x 1.9 mm</p>	<p><b>Step 30</b></p> <p>⊖ 1 x 2.9 mm ⊕ 1 x 1.6 mm</p>	

\* Measurements are according to overall screw length.

\* Screw maps are meant to be used only with **iFixit repair guides**.



# IPHONE 5

## Power Button Replacement

### TOOLS

- iPhone 5-Point Pentalobe Screwdriver
- iPhone SIM Card Eject Tool
- Phillips #00 Screwdriver
- Plastic Opening Tools
- Small suction cup
- 2.5 mm Flathead Screwdriver
- Spudger

**VIEW THE GUIDE:**  
[ifix.gd/guide10703](https://ifix.gd/guide10703)

**FIND MORE SCREW MAPS:**  
[ifixit.com/info/screwmaps](https://ifixit.com/info/screwmaps)