

<p><b>Step 1</b></p> <p>⊕ 2 x 3.6 mm</p>	<p><b>Step 6</b></p> <p>⊕ 2 x 1.2 mm 1 x 1.6 mm</p>	<p><b>Step 10</b></p> <p>⊕ 1 x 4.1 mm 1 x 2.2 mm</p>	<p><b>Step 15</b></p> <p>⊕ 2 x 1.3 mm</p>	<p><b>Step 20</b></p> <p>⊕ 4 x 1.2 mm</p>
<p><b>Step 21</b></p> <p>⊕ 1 x 1.4 mm 1 x 2.6 mm</p>				

\* Measurements are according to overall screw length.

\* Screw maps are meant to be used only with **iFixit repair guides**.



**IPHONE 5**  
Display Assembly  
Replacement

**TOOLS**

- Phillips #00 Screwdriver
- Plastic Opening Tools
- Small suction cup
- iPhone 5-Point Pentalobe Screwdriver

**VIEW THE GUIDE:**  
[ifix.gd/guide10906](https://ifix.gd/guide10906)

**FIND MORE SCREW MAPS:**  
[ifixit.com/info/screwmaps](https://ifixit.com/info/screwmaps)