

## Step 1

★ 2 x 3.6 mm

## Step 6

⊕ 2 x 1.2 mm  
1 x 1.6 mm

## Step 10

⊕ 1 x 1.8 mm  
1 x 1.6 mm

\* Measurements are according to overall screw length.

\* Screw maps are meant to be used only with **iFixit repair guides**.



## IPHONE 5

### Battery Replacement

#### TOOLS

- iPhone 5-Point Pentalobe Screwdriver
- Phillips #00 Screwdriver
- Small suction cup
- Plastic Opening Tools

**VIEW THE GUIDE:**  
[ifix.gd/guide10587](https://ifix.gd/guide10587)

**FIND MORE SCREW MAPS:**  
[ifixit.com/info/screwmaps](https://ifixit.com/info/screwmaps)