

Step 1

★ 2 x 3.6 mm

Step 4

★ 1 x 2.5 mm

* Measurements are according to overall screw length.

* Screw maps are meant to be used only with **iFixit repair guides**.



IPHONE 4

Battery Replacement

TOOLS

- iPhone 5-Point Pentalobe Screwdriver
- Phillips #000 Screwdriver
- Phillips #00 Screwdriver
- Plastic Opening Tools

VIEW THE GUIDE:
ifix.gd/guide3141

FIND MORE SCREW MAPS:
ifixit.com/info/screwmaps